

User Manual

Web Interface

MC Technologies Router

MC-MRL/MC-MRL-4 MC-MRH/MC-MRH-4 MC-MRE/MC-MRE-4



Router Description

Mobile radio routers were designed for industrial use.

They allow switching as needed between mobile radio routers with high and medium bandwidth.

Advantages at a glance:

- Easy expansion of protected networks.
- High-security data transfer via IPsec or OpenVPN tunnel, plus integrated firewall.
- Easy and identical configuration of router family via integrated web server, USB stick or "remote".
- Compatible with mobile networks world-wide - can be used internationally.
- Event alerts by SMS and email.
- Top-hat rail mounting.
- Integrated logbook records device-specific events.
- Use of applications with RS232, RS485 or M-Bus interfaces on demand (only MC-MRL/MC-MRH/MC-MRE)
- Use of integrated GPS receiver for positioning on demand (only MC-MRH/MC-MRH-4).
- Delivered ready-to-use, including power supply plug, Ethernet connecting cable and mobile radio antenna.
- SIM cards are not included in the standard scope of delivery.



Contents

1. Configuration via the integrated web interface	5
1.1 Preparations	5
1.2 Configuration	5
1.2.1 Configuration via web interface	5
1.2.2 Local IP address is not (longer) known - configuration button	5
1.2.3 Resetting all parameters	5
1.3 Status	6
1.3.1 Radio	6
1.3.2 Network Connections	7
1.3.3 I/O Status	8
1.3.4 ComSERVER (Only for MC Router with RS232 or RS485 interface on X1)	8
1.3.5 Routing Table	8
1.3.6 DHCP Leases	9
1.4 Local Network	9
1.4.1 IP Configuration	9
1.4.2 DHCP Server	10
1.4.3 Local Static Routes	11
1.5 Wireless Network	12
1.5.1 Radio Set-up	12
1.5.2 SIM (SIM1)	13
1.5.3 Backup SIM (SIM2)	14
1.5.4 SMS Configuration	14-15
1.5.5 Packet Data Set-up	16
1.5.6 Wireless Static Routes	17
1.5.7 DynDNS	18
1.5.8 Connection Check	18
1.6 Network Security	19-20
1.6.1 General Set-up (Firmware 1.xx.x)	19-20
1.6.1 General Set-up (Firmware 2.xx.x)	20
1.6.2 Firewall	21
1.6.3 NAT Table (Port forwarding)	22
1.7 VPN	23-25
1.7.1 IPsec	23-25
1.7.1.1 Connections	23-25
1.7.1.2 Certificates	26-27
1.7.1.3 Status	27
1.7.2 OpenVPN	28-30
1.7.2.1 Connections	28-30
1.7.2.2 Port Forwarding	31
1.7.2.3 Certificates	31-32
1.7.2.4 Static Keys (Preshared Key)	32
1.7.2.5 Status	32
1.8 I/O	33
1.8.1 Inputs	33
1.8.2 Outputs	33-34
1.8.3 Phonebook	34
1.8.4 Socket Server	34
1.9 System	35
1.9.1 Hardware	35
1.9.2 Software	36
1.9.3 System Configuration	36-38
1.9.4 User	39
1.9.5 Log File	39
1.9.6 ComSERVER (Only for MC Router with RS232 or RS485 interface on X1)	40
1.9.7 SMTP configuration	40-41
1.9.8 SMTP configuration - sending emails	41
1.9.9 Configuration Up-/Download	42
1.9.10 RTC - Setting the time and date / Time Server	43
1.9.11 Reboot - restarting the router	44
1.9.12 Firmware Update	44

2. Additional functions		
2.1 Router configuration using SSH and XML file		45
2.1.1 Download configuration via SSH		45
2.1.2 Upload configuration via SSH		45
2.2 Sending and receiving IO status, email, SMS and router status using XML files via the router socket server		46
2.2.1 Sample XML files		46
2.2.2 Functions test using Windows HyperTerminal		47
2.3 Using the integrated GPS receiver in the MC-MRH router		48
2.3.1 Activating the GPS function		48
2.3.2 Displaying the GPS coordinates in the web interface		49
2.3.3 Receiving the GPS coordinates as an SMS		49
2.3.4 GPS coordinates as an XML file		49

1. 1. Configuration via the integrated web interface

1.1 Preparations

1. Hook the router up to the power supply using connection "P1" , "P2" or "POW".
2. To configure, connect the PC and the router to Ethernet port "ETH1" using an Ethernet cable.
3. For configuration, you will need a browser (i.e. Mozilla Firefox, Microsoft Internet Explorer, etc.) on a PC.
The router must be connected to the power supply. The PC to be used for configuration must be connected to an Ethernet port on the router.

1.2 Configuration

1.2.1 Configuration via web interface


1. The PC must be set to "obtain IP address automatically".
This is the default setting for PCs.
2. Open a browser on the PC.
3. Type the IP address (default: 192.168.0.1) in the address field.
4. For authentication purposes a user name and password must be entered. The default settings for the user name and password are both "admin", which should be entered in the corresponding fields. For your security, the password setting can be changed at any time using the "System/User" menu item on the web interface (see Page 39).

1.2.2 Local IP address is not (longer) known – configuration button

To reconfigure the router using the default IP address you will need to use the configuration button on the rear side of the device. This function depends on the setting you defined in Section 1.9.3 "Reset button".

Web access reset


The router is set to "Web access reset" unless you change the default setting. Press the configuration button for at least 5 seconds using a pointed object. The router web interface can be temporarily readdressed using the default IP address (192.168.0.1) for the Ethernet (LAN) connection. The configuration settings will not be lost when doing so.

 **Important note!** The router does not supply any IP address to the connected PC via DHCP. You must thus assign a fixed IP address to the PC (e.g. 192.168.0.2, default gateway 192.168.0.1).

You will now have access to web management using the default access data. Please check the settings for the router IP address, user name and password and make any changes required.

Factory reset

You changed the setting to "Factory reset" (see Item 1.9.3 "System Configuration/Reset button"). Press the configuration button for at least 5 seconds using a pointed object. The router web interface can be readdressed using the default IP address (192.168.0.1) for the Ethernet (LAN) connection.

 **Important note!** All configuration settings will be deleted and reset to the "Factory Defaults" setting.

1.2.3 Resetting all parameters on the web interface

Resetting of all router settings to the factory default mode can be carried out via the internal web interface. Please click on the "Apply" button for the "Reset to Factory Defaults" function in the "System/Configuration Up-/Download" sub-menu.

1.3 Status

Display basic status information.

1.3.1 Radio


Display mobile connection.

Radio Status

Provider	Name of mobile service provider.	
Networkstatus	Status in cellular network.	
	Registered home:	Registered in the cellular network.
	Roaming:	Registered in a third-party cellular network.
	Waiting for PIN:	Waiting for PIN to be entered.
	Waiting for PUK:	Locked SIM card must be unlocked with PUK.
	Wrong PIN:	Wrong PIN configured in the router.
	No SIM Card:	Put SIM card in.
	Power off:	The GSM module is still off.
Signal level	Display receive level.	
Packet data	Offline:	No packet data connection.
	GPRS online:	Active GPRS connection.
	EDGE online:	Active EDGE connection.
	UMTS online:	Active UMTS connection.
	HSDPA/HSUPA online:	Active HSDPA/HSUPA connection.
	LTE online:	Active LTE connection.
SIM #1 IMSI	Specification of IMSI (International Mobile Subscriber Identity) by the SIM card.	
Local area code	Number in cellular network via current location.	
Cell ID	Clear recognition of a GSM cell in the cellular network.	

1.3.2 Network Connections

Status information on mobile connection and on local Ethernet network.



MC-MRL

Network Connections

Wireless Network	
Link	TCP/IP connected
IP Address	37.84.74.12
Netmask	255.255.255.248
DNS Server	10.74.210.210
Sec. DNS Server	10.74.210.211
Expires	6 601 sec.
RX bytes	4 194 364
TX bytes	142 590

Local Network	
Link	connected
IP Address	192.168.196.253
Netmask	255.255.255.0

Network Connections

Wireless Network	
Link	TCP/IP connected: Active GPRS/EDGE/UMTS/HSPA or LTE packet data connection in cellular network. VPN connected: Active VPN connection via the cellular network. Not connected: No packet data connection in the cellular network.
IP Address	Allocated IP address from the cellular network.
Netmask	Allocated net mask from the cellular network.
DNS Server	IP address of the DNS server.
Sec. DNS Server	IP address of the alternate DNS server.
Expires	Only MC-MRL (LTE) remainder duration until prompt for a new IP address.
RX bytes	Sum of received data since last login to cellular network.
TX bytes	Sum of sent data since last login to cellular network.
Local Network	
Link	Connected: The local Ethernet is active. Not connected: The local Ethernet is not active.
IP Address	Router IP address in the local network.
Netmask	Router net mask in the local network.

1.3.3 I/O Status

Status information of I/O interfaces IN and OUT.

Input	Signal	Event
#1	Low: The signal is low. High: The signal is high.	None: No event has been triggered. SMS: An SMS is being sent. E-Mail: An email is being sent.
Output	Signal	Event
#1	ON: Output active. Off: Output is not active.	Based on: Manual ON, Remote Controlled ON, Radio Network ON, Packet Service ON, VPN Service ON, Incoming Call ON or Connection lost ON.

1.3.4 ComSERVER (only for MC Router with RS232 or RS485 interface on X1)

Status display of integrated ComSERVER

See also 1.9.6. ComSERVER

1.3.5 Routing Table

Display of current routing table.

Destination	Gateway	Genmask	Flags	Metric	Ref	Use	Iface
0.0.0.0	37.84.74.9	0.0.0.0	UG	0	0	0	eth2
37.84.74.8	0.0.0.0	255.255.255.248	U	0	0	0	eth2
127.0.0.0	0.0.0.0	255.0.0.0	U	0	0	0	lo
192.168.196.0	0.0.0.0	255.255.255.0	U	0	0	0	br0

1.3.6 DHCP Leases


Display allocation of MAC address to IP address of terminal equipment connected to the local Ethernet. Connected terminal devices with a fixed IP address will not be shown.



1.4 Local Network

1.4.1 IP Configuration

Setup of local IP address and subnet mask for router. Set your parameters and click "Apply". Your parameters have been saved but not yet applied. To apply the setup, restart the router.



IP Configuration

Current Address	
IP Address	Current local IP address of the router. If you forget the IP address and would like to configure the router, follow the instructions under 1.2 "Configuration" on Page 5.
Subnet Mask	Current subnet mask.
Type of IP address assignment	Static (default): The IP address has been set. DHCP: The IP address and the subnet mask are obtained dynamically from a connected DHCP server.
Alias Addresses	
IP Address	Alias addresses how the router can be reached alternatively (up to eight other IP addresses). Click "New" and add the other IP addresses, as well as the corresponding subnet masks.
Subnet Mask	

1.4.2 DHCP Server


An IP address can be allocated automatically to local equipment connected via Ethernet using DHCP (Dynamic Host Configuration Protocol).

DHCP Server

DHCP Server	Disabled/Enabled: Click "Enabled" if the router should allocate the IP addresses to the connected terminal equipment as the DHCP server at start-up.
Domain Name	Domain name to be broadcast via DHCP.
Lease Time (d,h,m,s)	Validity period of allocated network configuration.
Dyn. IP address	Disabled/Enabled: Click "Enabled" if an IP address should be dynamically allocated to the connected terminal equipment in a set range.
Begin IP Range	Starting address for the address range from which IP addresses should be distributed.
End IP Range	Ending address for the address range from which IP addresses should be distributed.
Static IP address allocation	Static allocation of the IP address using the MAC address.
Client MAC address	MAC address of the terminal equipment.
Client IP address	IP address of the terminal equipment. Static allocation of the IP addresses should not overlap with the dynamic IP addresses. An identical IP address should not be used in multiple static allocations.

1.4.3 Local Static Routes

Data packets from the local network can be defined by static routes using other gateways for alternative routes.



Local Static Routes

Network	Network in CIDR notation: IP address / Net mask Example: xxx.xxx.xxx.xxx/yy (x..=IP address; yy=net mask) Example: yy=24 (number of binary "ones") => net mask = 255.255.255.0
Gateway	The gateway how this network can be reached.

1.5 Wireless Network

Set-up for using the cellular network.


1.5.1 Radio Set-up

Radio Set-up

Frequency	Set-up of the frequency range of the cellular network in which the router should work.	
UMTS Freq.	Set-up of the UMTS frequency range of the cellular network in which the router should work.	
	UMTS off:	Deactivate UMTS and HSPA.
Backup SIM (SIM2)	Disabled:	The back-up SIM (SIM2) is inactive.
	Enabled:	Back-up SIM active if a connection to the provider of the standard SIM (SIM1) for the set "provider timeout" period fails. The duration of the back-up SIM (SIM2) is determined by setting the "back-up runtime". After this period the standard SIM is reactivated.
	Always:	Only the back-up SIM (SIM2) is active.
	Input 1:	Switch to back-up SIM (SIM2) if input 1 high is on level.
Provider Timeout	Amount of time in minutes after which the back-up SIM card (SIM2) should be switched to if the primary cellular network (SIM1) is down.	
Backup Runtime	Amount of time in hours after which the primary cellular network (SIM1) should be switched back on.	
Daily relogin	Disabled:	Deactivate daily login.
	Enabled:	Activate daily login. Daily login first attempts to log onto primary cellular network (SIM1).
Time	Time of day at which the router independently logs out of the cellular network and logs back in. Relogin first attempts to log onto primary cellular network (SIM1).	

1.5.2 SIM (SIM1)

Settings for the primary mobile connection via SIM1.



SIM (SIM1)

Country	Preselection of the country in which the router should operate. Under the menu option „Provider“, you can then select the mobile service provider of the selected country.
PIN	PIN entry for SIM card SIM1.
Roaming	Set-up for use of third-party cellular networks. Enabled: The router can log onto third-party networks. The "Auto" setting selects the provider with the strongest signal. This may result in additional cost, depending on the mobile service contract. Alternatively, you can choose a provider yourself. Disabled: Roaming is deactivated and only the local network of the provider is used. If this network is not available, the router cannot connect to the Internet.
Provider	Selection of the provider via which the router connects to the Internet. The selection changes according to the country selected under "Country" in the menu. Auto: The router selects the provider automatically.
Username	User name for access.
Password	Password for access. The user name and the password are given to you by your mobile service provider. Do not leave the user name and password blank during configuration, even if the mobile service provider does not require any specific input!
APN	The APN is given to you by your mobile service provider. APN: (Access Point Name) is the name of the access point in the mobile service provider's packet data network.
Authentication	The default setting is "All protocols". Some providers require a specific authentication setting (refuse MSCHAP, CHAP only, PAP only) here. Consult your provider if necessary.

1.5.3 Back-up SIM (SIM2)

Settings for the back-up mobile connection via SIM2.

Back-up SIM (SIM2)

The same settings apply here as for Item 1.5.2 SIM (SIM1) (see Page 13). The second SIM card (SIM2) is located inside the router housing. To insert or remove the SIM2 card, remove the back panel of the router.



1.5.4 SMS Configuration

Controlling the mobile router by SMS

Under "SMS Control", click Enabled. Define an SMS password for security. The password can comprise up to 7 alphanumeric characters.

SMS Syntax

Commands are inputs using the following SMS syntax:

```
#<password>:<command>
<password> = ('A'-'Z', '0'-'9')      //      Up to 7 alphanumeric characters

<command> = SET:<sub_cmd>           //      Set command (ON)
<command> = CLR:<sub_cmd>           //      Clear command (OFF)
<sub_cmd> = OUTPUT                  //      Output set to ON/OFF
<sub_cmd> = IPSEC                   //      IPsec VPN 1 ON/OFF
<sub_cmd> = IPSEC:n                 //      IPsec VPN n ON/OFF, n={1..x}

<command> = SEND:STATUS              //      Send a status SMS to the caller
<command> = RESET                   //      Reset all alarms
<command> = REBOOT                   //      Router reboot
```

Example:


Turn on the I/O interface output. The (example) password is: "pw1212". The SMS sent to the router's call number should then have the following content: #pw1212:SET:OUTPUT.

Forwarding an SMS to a socket server

The router can forward received SMS messages to a terminal device through the Ethernet interface. A socket server must be installed on the terminal device to receive XML files.

Under "SMS forward", click Enabled. Enter the recipient's IP address and the port of the terminal device you want to talk to. The default value for the server is Port 1432. The received SMS is forwarded in the following example format:

Important note!


 The call number should be included as an entry in the phonebook (see Page 34) in order for the router to identify it.

Example:

```
<?xml version="1.0"?>
<cmgr origaddr="+49172123456789" timestamp="10/05/21,11:27:14+08">
SMS message</cmgr>
```

origaddr = Sender's call number

timestamp = Time-stamp of the Service Centre in GSM 03.40 format



SMS Configuration

SMS control	Disabled: Remote control of router by SMS not possible. Enabled: Remote control of router by SMS activated.
SMS Password	SMS password for remote control.
SMS forward	Disabled: Forwarding of SMS message via Ethernet not possible. Enabled: Forwarding of SMS message via Ethernet activated.
Server IP address	IP address to which the SMS message should be forwarded.
Server Port (default 1432)	Port to which the SMS message should be forwarded.

1.5.5 Packet Data Set-up

Activation and deactivation of the packet data connection via GPRS, EDGE, UMTS, HSPA or LTE.

The screenshot shows the 'MC-MRL' configuration interface. On the left is a sidebar with a tree view containing categories like Logout, Status, Local Network, Wireless Network, Network Security, VPN, I/O, and System. Under 'Wireless Network', 'Packet Data Setup' is selected and highlighted with a red arrow. The main content area is titled 'MC-MRL' and contains the 'Packet Data Setup' form. The form includes the following settings:


- Packet data:** Radio buttons for Disabled and Enabled. 'Enabled' is selected.
- Debug Mode:** Radio buttons for Disabled and Enabled. 'Disabled' is selected.
- Allow Compression:** Radio buttons for Disabled and Enabled. 'Enabled' is selected.
- MTU (default 1500):** A text input field containing '1500'.
- Event:** A dropdown menu with 'Initiate' selected.
- Manual DNS:** Radio buttons for Disabled and Enabled. 'Disabled' is selected.
- DNS Server:** A text input field containing '0.0.0.0'.
- Sec. DNS Server:** A text input field containing '0.0.0.0'.
- Apply:** A button at the bottom of the form.

Packet Data Set-up

Packet data	<p>Disabled: Access to GPRS/EDGE/UMTS/HSPA or LTE deactivated.</p> <p>Enabled: Allow access to GPRS/EDGE/UMTS/HSPA or LTE.</p>
Debug Mode	<p>Disabled: Detailed information on packet data connection not saved in the log file.</p> <p>Enabled: Detailed information on packet data connection saved in the log file.</p>
Allow Compression	<p>Disabled: Data compression of the packet data connection is deactivated.</p> <p>Enabled: Data compression of the packet data connection is activated (default).</p>
MTU (default 1500)	Maximum packet size in bytes in the packet data network.
Event	<p>Definition of packet data connection start.</p> <p>Initiate: Automatic start.</p> <p>Initiate on Input #1: Start controlled through IN signal in the I/O interface.</p>
Manual DNS	<p>Disabled: Automatic DNS set-up. The DNS settings of the provider will be used.</p> <p>Enabled: Manual DNS set-up.</p>
DNS Server	IP address of the primary DNS server in the mobile service network.
Sec. DNS Server	IP address of the alternate DNS server in the mobile service network.

1.5.6 Wireless Static Routes

Data packets from the local network can be defined using static routes for alternative routes in the mobile service network.



Wireless Static Routes

Wireless Static Routes	
Network	Network in CIDR notation.
Gateway	The gateway via which this network can be reached.

1.5.7 DynDNS

The router IP address in the cellular network/Internet is allocated dynamically by the mobile service operator. A name can be allocated to the dynamic IP address using a DynDNS provider, via which the router can then be reached over the Internet. The DynDNS Client must be saved and activated in the router accordingly.

i Note: For this to work, the provider must have allocated a public IP address to the router, not a private one. This is not the case with all providers. DynDNS cannot replace a static IP address and has limited reliability.


DynDNS Set-up

Status	<p>Disabled: Deactivate DynDNS client.</p> <p>Enabled: Activate DynDNS client.</p>
DynDNS Provider	<p>Select the name of the provider with whom you are registered, i.e. DynDNS.org, TZO.com, dhs.org., selfHost.de, custom DynDNS.</p> <p>Use the "custom DynDNS" setting to select your preferred DynDNS provider. Please also enter the provider's server address under "DynDNS Server".</p>
DynDNS Username	Enter the username for your DynDNS account here.
DynDNS Password	Enter the password for your DynDNS account here.
DynDNS Hostname	<p>The host name selected for this router for DynDNS service.</p> <p>Your router can then be reached under this host name.</p>

1.5.8 Connection Check

For continuous connection monitoring, use "Connection Check" to check for a packet data connection in the mobile service network. If the connection is lost, an action can be configured for establishing a new connection.

i Note: Please note that frequent connection checks can lead to increased data traffic and corresponding costs.



Connection Check

Status	Disabled: Connection check is deactivated (default). Enabled: Connection check is activated.
Host #1 ... #3	IP address or host name of the reference point for the connection check. "Local" option, when dealing with an address which can be reached via a VPN tunnel.
Check every	Check interval in minutes.
Max. retry	Number of repetitions until the configured action "Activity" is performed.
Activity	Reboot: Restart the router. Reconnect: Re-establish packet data connection. Relogin: Restart the cellular interface by redialing the mobile service network. None: None.

1.6 Network Security


1.6.1 General Set-up (Firmware 1.xx.x)

These settings apply for routers with 1.xx.x firmware (see Release Version under "System/Hardware").



Important note!

Routers with Release 1.xx.x firmware cannot be updated to Version 2.xx.x. Please contact the manufacturer.



General Set-up

Firewall	Disabled: The integrated firewall is deactivated, no filtering of data packets. Enabled: The integrated firewall is activated (default).
Port forwarding via NAT table	Disabled: Port forwarding via NAT table is blocked. Enabled: Port forwarding via NAT table is allowed.
Block outgoing Netbios	Disabled: Outgoing NetBIOS requests are allowed. Enabled: Outgoing NetBIOS requests are blocked (default).
Ping (ICMP) external	Disabled: A ping request from the external IP network to the router is ignored (default). Enabled: A ping request from the external IP network to the router is returned.
Web based Management external	Disabled: External configuration via the web interface is not possible (default). Enabled: External configuration via the web interface is possible.
NAT (Masquerade) external	Disabled: No IP masquerading performed. Enabled: IP masquerading is activated. Communication from a private, local network to the Internet is allowed (default).
Device access via SSH	Disabled: Local SSH access to the router is not possible (default). Enabled: Local SSH access to the router is possible.
External access via SSH	Disabled: Remote SSH access to the router is not possible (default). Enabled: Remote SSH access to the router is possible.


1.6.2 General Setup (Firmware 2.xx.x)

These settings apply for routers with 2.xx.x firmware (see Release Version under "System/Hardware").



Important note!

Routers with Release 1.xx.x firmware cannot be updated to Version 2.xx.x. Please contact the manufacturer.



General Set-up


Firewall	Disabled: The integrated firewall is deactivated, no filtering of data packets. Enabled: The integrated firewall is activated (default).
Port forwarding via NAT table	Disabled: Port forwarding via NAT table is blocked. Enabled: Port forwarding via NAT table is allowed.
Block outgoing Netbios	Disabled: Outgoing NetBIOS requests are allowed. Enabled: Outgoing NetBIOS requests are blocked (default).
Ping (ICMP) external	Disabled: A ping request from the external IP network to the router is ignored (default). Enabled: A ping request from the external IP network to the router is returned.
External SNMP access	Disabled: Remote SNMP Access is not possible. Enabled: Remote SNMP Access is possible.
External Web based Management via HTTP	Disabled: External configuration via the web interface is not possible (default). Enabled: External configuration via the web interface is possible.
NAT (Masquerade) external	Disabled: No IP masquerading performed. Enabled: IP masquerading is activated. Communication from a private, local network to the Internet is allowed (default).
Device access via SSH	Disabled: Local configuration via the web interface and https is not possible (default). Enabled: Local configuration via the web interface and https is possible.
External access via SSH	Disabled: External configuration via the web interface and https is not possible (default). Enabled: Configuration via the web interface and https is possible.

1.6.3 Firewall

The MCT router includes a Stateful Packet Inspection Firewall.

The firewall can be turned on or off (see "Network Security Setup," menu point "Firewall.") The firewall is active by default and blocks incoming data traffic. Outgoing data traffic is still possible.

i The firewall rules are applied from up to down.



Firewall

Incoming Traffic	
Protocol	TCP, UDP, ICMP, all
From IP	0.0.0.0/0 means all IP addresses. To enter an address range, use CIDR notation.
To IP	
From Port	(only with TCP and UDP) You have the following options:
To Port	<ol style="list-style-type: none"> 1. Direct port input Example: From Port = 20, To Port = 30. 2. Any Examples: From Port or To Port = Any (Any means absolutely any port). 3. Port range Example: From Port or To Port = 80-90 (all ports from 80-90).
Action	Accept: Pass data packets. Reject: Data packets are rejected. Drop: Data packets may not pass, the sender does not receive notification.
Log	Logging firewall rules. Yes: Event is logged. No: Event is not logged (default).
New	A new firewall rule is added below the last rule. Delete: The rule is deleted.
Outgoing Traffic	
Lists the installed firewall regulations. They apply for outgoing data connections that were internally initiated to communicate with a remote destination device. Factory settings: The factory settings include a rule allowing all outgoing connections.	
i Note: If no rule is set, all outgoing connections are blocked (except VPN).	
Protocol	TCP, UDP, ICMP, all
From IP	0.0.0.0/0 means all IP addresses. To enter an address range, use CIDR notation.
From Port	(Only evaluated for TCP and UDP logs.) You have the following options:
To Port	<ol style="list-style-type: none"> 1. Direct port input Example: From Port = 20, To Port = 30. 2. Any Examples: From Port or To Port = Any (Any means absolutely any port). 3. Port range Example: From Port or To Port = 80-90 (all ports from 80-90).
Action	Accept: Pass data packets. Reject: Data packets are rejected. Drop: Data packets may not pass, the sender does not receive notification.
	Log: Logging of firewall rules. Yes: Event is logged. No: Event is not logged (default).
New	A new firewall rule is added below the last rule. Delete: The rule is deleted.

1.6.4 NAT table (port forwarding)

Rules for NAT (Network Address Translation).

The router has only one IP address, via which it can be accessed externally.

Data packets can be redirected to internal IP address ports via additional transmitted port numbers.

NAT table

Protocol	TCP, UDP, ICMP
In Port To Port	(only with TCP and UDP) You have the following options: 1. Direct port input Example: In Port = 20, To Port = 30. 2. Port range Example: In Port = 80-90 To Port = 100-110.
To IP Masq	0.0.0.0/0 means all IP addresses. To enter an address range, use CIDR notation. For every individual rule, you can determine if IP masquerading should be applied. Yes: IP masquerading is activated, reply to cellular network is possible. No: (Default) reply to cellular network is not possible.
Comment	Entering a comment.
Log	Logging firewall rules. Yes: Event is logged. No: Event is not logged (default).
New	The "New" button allows a new rule to be added under the last rule. The "Delete" button deletes the rule from the table.



Note: After clicking "Apply", perform a reboot (see Page 44) or restart the router (interrupt the power supply).

1.7 VPN

1.7.1 IPsec


1.7.1.1 Connections

IPsec (Internet Protocol Security) is a security protocol used for communicating over IP networks.

For a VPN connection, the IP addresses of the VPN remote peers must be known and addressable.

The VPN remote peer must support IPsec with the following configuration:

- Authentication by X.509 certificates or Preshared Secret Key (PSK)
- ESP
- Diffie-Hellman Group 2 or 5
- 3DES or AES encryption
- MD5 or SHA-1 hash algorithms
- Tunnel mode
- Quick mode
- Main mode
- SA lifetime (1 second to 24 hours)



IPsec Connections			
Monitor DynDNS		No	
Check interval		600 sec.	
Enabled	Name	Settings	IKE
Yes	Router1	Edit	Edit
No	vpn2	Edit	Edit
No	vpn3	Edit	Edit
No	vpn4	Edit	Edit
No	vpn5	Edit	Edit
No	vpn6	Edit	Edit
No	vpn7	Edit	Edit
No	vpn8	Edit	Edit
Apply			

IPsec Connections

Monitor DynDNS	If DynDNS is used as "Remote Host", the "Monitor DynDNS" function should be set to "Yes".
Check interval	Check interval in seconds.
Enabled	Activate or deactivate VPN connection.
Name	Arbitrary name of VPN connection.
Settings	VPN connection settings.
IKE	The "Edit" menu includes settings to establish IKE (Internet Key Exchange protocol) automatic key management for IPsec (see Page 25).

IPsec Connection Settings > Edit

IPsec Connection Settings	
Name	vpn1
VPN	<input type="radio"/> Disabled <input checked="" type="radio"/> Enabled
Authentication	X.509 Remote Certificate
Remote Certificate	None
Local Certificate	None
Remote ID	
Local ID	
<input type="checkbox"/> Virtual Remote Address	192.168.9.2
Address Remote Network	192.168.9.0/24
Address Local Network	192.168.0.0/24
Connection NAT	None
Remote Connection	Accept
<input type="checkbox"/> Autoreset	60 min.
<div>IKE</div> <div>Apply</div>	

Remote Connection "Accept"

IPsec Connection Settings	
Name	vpn1
VPN	<input type="radio"/> Disabled <input checked="" type="radio"/> Enabled
Remote Host	
Authentication	X.509 Remote Certificate
Remote Certificate	None
Local Certificate	None
Remote ID	
Local ID	
Address Remote Network	192.168.9.0/24
Address Local Network	192.168.0.0/24
Connection NAT	None
Remote Connection	Initiate
<input type="checkbox"/> Autoreset	60 min.
<div>IKE</div> <div>Apply</div>	

Remote Connection "Initiate ..."


IPsec Connection Settings

Name	Name of the VPN connection.	
VPN	Active = Enabled, Inactive = Disabled.	
Authentication	<p>X.509 Remote Certificate: Each VPN participant has a private, secret key as well as a public key in the form of a X.509 certificate which contains further information about its owner and a certification authority (CA).</p> <p>Preshared Secred Key (PSK): Each VPN participant knows a shared password.</p> <p>X.509 Remote + CAuth: Like an X.509 certificate but with entry of the user name and password (e.g. when using Shrew Soft as a VPN client).</p>	
Remote Certificate	VPN remote peer certificate. The certificate must be loaded ahead of time.	
Local Certificate	Local certificate with which the router identifies itself to the VPN remote peer (machine certificate, PKCS#12.) The certificate must be loaded ahead of time.	
Remote ID	If the field is left empty (default,) the information from the certificate is used. Name for identification by remote peer. This must correspond to the information from the router certificate.	
Local ID	If the field is left empty (default,) the information from the certificate is used. The local ID allows you to set the name with which the router identifies itself to the remote peer. For more details, see Remote ID.	
Virtual Remote Address	Virtual remote IP address when using clients that cannot connect networks (e.g. PC with Shrew Soft VPN software, smartphones, etc.).	
Address Remote Network	IP address/subnet mask of the remote network to which the VPN connection needs to be established.	

IPsec Connection Settings

Address Local Network	IP address/subnet mask of the local network.	
Connection NAT	None: No NAT on other IP addresses. Local 1:1 –NAT -> NAT to local Network: 1 to 1 NAT on the local network. Setting of the start IP address.	
Remote Connection	Direction of connection establishment: Accept: Wait for the remote peer to establish the connection. Initiate: The router establishes the connection. Initiate on SMS: Connection established after reception of valid SMS. Initiate on Call: Connection established after valid call. Initiate on Input: Connection established after switch signal on IN of the I/O interface.	
Autoreset	Click here and set a time in minutes after which the connection should be automatically disconnected.	

IPsec Connection IKE > Edit



MC-MRL

IPsec - Internet Key Exchange Settings

Name: vpn1

Phase 1 ISAKMP SA

ISAKMP SA Encryption: AES-128

ISAKMP SA Hash: all

ISAKMP SA Lifetime: 3600 sec.

Phase 2 IPsec SA

IPsec SA Encryption: AES-128

IPsec SA Hash: all

IPsec SA Lifetime: 28800 sec.

Perfect Forward Secrecy (PFS): Yes

DH/PFS Group: 2/modp1024

Rekey: Yes

Dead Peer Detection: Yes

DPD Delay: 30 sec.

DPD Timeout: 120 sec.

Settings Apply

IPsec Connection IKE

IPsec - Internet Key Exchange Settings	Name of the VPN connection.
Phase 1 ISAKMP SA	
ISAKMP SA Encryption	AES-128 (default). AES-192, AES-256, 3 DES.
ISAKMP SA Hash	The setting "all" accepts either MD5 or SHA-1.
ISAKMP SA Lifetime	Life cycle of a key in seconds (3600 = 1 hour).

IPsec Connection IKE

Phase 2 IPsec SA	Unlike Phase 1 ISAKMP SA (key exchange,) this is where the procedure for Data exchange is determined. It can differ from the key exchange procedure.
IPsec SA Encryption	AES-128 (default). AES-192, AES-256, 3 DES.
IPsec SA Hash	The setting "all" accepts either MD5 or SHA-1.
IPsec SA Lifetime	Life cycle in seconds for the key specified for IPsec SA. 28800 seconds = 8 hours (default). 86400 seconds = 24 hours (maximum).
Perfect Forward Secrecy (PFS)	Yes: Perfect Forward Secrecy activated. No: Perfect Forward Secrecy deactivated.
DH/PFS Group	Key exchange procedure (Diffie-Hellman groups for Internet Key Exchange (IKE)). 5/modp1536 = High encryption. 2/modp1024 = Normal encryption (default).
Rekey	Yes: A new key will be brokered. No: No new key will be brokered.
Dead Peer Detection	Recognition of validity and resulting action in case of interruption of IPsec connection. Yes: Dead Peer Detection activated (i.e. Restart at VPN Initiate). No: No Dead Peer Detection.
DPD Delay	Time interval to next check.
DPD Timeout	Time period after which the connection to the remote peer should be declared inactive. Default value: 120 seconds. Maximum: 86400 seconds (24 hours).

1.7.1.2 Certificates

The router authenticates itself to the remote peer with a certificate that can be uploaded onto the router. By clicking "Apply", you upload the certificate onto the router.

MC-MRH

IPsec Certificates

Load Remote Certificate (.cer .crt)

Upload Keine Datei ausgewählt

Load Own PKCS#12 Certificate (.p12)

Upload Keine Datei ausgewählt

Password

Remote Certificates

Name	Router1.crt	<input type="button" value="Delete"/>
------	-------------	---------------------------------------

Own Certificates

Name	Router5.p12	<input type="button" value="Delete"/>
CA Certificate		<input checked="" type="checkbox"/>
Machine Certificate		<input checked="" type="checkbox"/>
Private Key		<input checked="" type="checkbox"/>

Certificates

Load Remote Certificate	Upload	- Upload the remote peer certificate (.cer .crt). Under VPN > IPsec > Connections > Settings > Edit, you assign the certificate for the VPN connection.
Load Own PKCS#12 Certificate	Upload	- Upload the certificate (in PKCS#12 format, xxx.p12) to be used for the local router. Under VPN > IPsec > Connections > Settings > Edit, you assign the certificate to the VPN connection.
	Password	- Enter the password given during exporting.
Remote Certificates		List of imported .cer /.crt certificates.
	Delete	- Delete a certificate.
Own Certificates		List of imported PKCS#12 certificates
	Delete	- Delete a certificate.

1.7.1.3 Status

[Logout](#)

- Status
- Local Network
- Wireless Network
- Network Security
- VPN
 - IPsec
 - Connections
 - Certificates
 - Status
 - OpenVPN
- I/O
- System

MC-MRH

IPsec Status			
Active IPsec Connections			
Name	Remote Host	ISAKMP SA	IPsec SA
vpn1	84.46.116.88	✓	✓

IPsec Status


Active IPsec Connections	An active VPN connection is indicated by a green symbol.
--------------------------	--

1.7.2 OpenVPN

1.7.2.1 Connections (Tunnel 1 and 2)


OpenVPN establishment of a virtual private network (VPN) via an encrypted connection.
Two OpenVPN tunnels can be set up at the same time (Tunnel 1 and Tunnel 2.)
The configuration of Tunnel 1 and Tunnel 2 is identical.

OpenVPN Connections



Select an OpenVPN connection and click "Edit".

OpenVPN Tunnel



Name	Arbitrary name of OpenVPN connection.
VPN	Enabled: OpenVPN Tunnel activated. Disabled: OpenVPN Tunnel deactivated.
Remote Host	IP address or URL of the remote peer to which the tunnel will be established.
Remote Port	Port of the remote peer to which the tunnel will be established (default 1194).
Protocol	Protocol selection (UDP or TCP).
LZO Compression	Disabled: Switched off or not allowed. Adaptive: (Data) adaptive compression switched on. Yes: Switched on but can be switched off from the server. No: Switched off but can be switched on from the server. Enabled: Compression allowed; type of compression determined by the server.
Allow Remote Float	Activate this option to accept authenticated packets from each IP address during OpenVPN connection. This option is recommended if IP addresses are used for dynamic communication.
Redirect Default Gateway	The default gateway is directed via the tunnel.
Local Port	Determines a fixed port for the OpenVPN client.

OpenVPN Tunnel X.509 Certificate

Authentication	X.509 Certificate
Local Certificate	LAB2.p12
TLS Authentication Key	None
Check Remote Certificate Type	<input type="checkbox"/>
Connection NAT	None
Encryption	AES 128 Bit

Authentication	X.509 Certificate - Authentication procedure for X.509 certificate.	
Local Certificate	Ascertains which certificate the router will use to identify itself to the VPN remote peer.	
TLS Authentication Key	Selection of a static key for an additional TLS Auth signature. The same key must then be used on the other side. The static key must have been generated and/or uploaded in advance under VPN > OpenVPN > Static Key.	
Check Remote Certificate Type	Activate this option to check the OpenVPN connection certificates.	
Connection NAT	None: No forwarding. Local 1:1 NAT: "One-to-one" forwarding to a local network (NAT to local network). Local Masquerding: The packets going out through the tunnel are rewritten to the router source address so that equipment on the router can access the other side of the tunnel. Port Forwarding: Forwarding with the setting described under 1.7.2.2. Host Forwarding: Forwarding to the fixed IP address of a connected terminal device (Forward to local Host).	
Encryption	Encryption algorithm for the OpenVPN connection.	

OpenVPN Tunnel Preshared Secret Key

Authentication	Preshared Secret Key
Preshared Secret Key	None
Remote Interface	172.16.0.2
Local Interface	172.16.0.1
Address Remote Network	192.168.9.0/24
Connection NAT	None
Encryption	BLOWFISH 128 Bit

Authentication	Preshared Secret Key – authentication procedure with a static key (Preshared Key).	
Preshared Secret Key	Ascertains preshared secret key the router uses to identify itself to the VPN remote peer.	
Remote Interface Certificate Type	Virtual, remote IP address of the remote peer certificate type.	
Local Interface	Virtual local IP address of the router.	
Address Remote Network	Address range of the remote network.	
Connection NAT	None: No forwarding. Local 1:1 NAT: "One-to-one" forwarding to a local network (NAT to local network). Local Masquerding: The packets going out through the tunnel are rewritten to the source address of the router to allow equipment on the router access to the other side of the tunnel. Port Forwarding: Forwarding with the setting described under 1.7.2.2. Host Forwarding: Forwarding to the fixed IP address of a connected terminal device (Forward to local Host).	
Encryption	Encryption algorithm for the OpenVPN connection.	

OpenVPN Tunnel User name/Password

Authentication	Username/Password ▾
CA Certificate	None ▾
Check Remote Certificate Type	<input type="checkbox"/>
Username	<input type="text"/>
Password	<input type="password"/>
Connection NAT	None ▾
Encryption	BLOWFISH 128 Bit ▾

Authentication	Username/Password - Set-up of user name and password.	
CA Certificate	Enter the OpenVPN server CA certificate.	
Check Remote Certificate Type	Specifying whether the remote certificate should be evaluated.	
Username	Enter user name.	
Password	Enter password.	
Connection NAT	None: Local 1:1 NAT: Local Masquerading: Remote Masquerading: Port Forwarding: Host Forwarding:	No forwarding. "One-to-one" forwarding to a local network (NAT to local network). The packets going out through the tunnel are rewritten to the router source address so that equipment on the router can access the other side of the tunnel. The packets coming in through the tunnel are rewritten on the local router address. Forwarding with the setting described under 1.7.2.2. Forwarding to the fixed IP address of a connected terminal device (Forward to local Host).
Encryption	Encryption algorithm for the OpenVPN connection.	


Keep Alive

<input checked="" type="checkbox"/> Keep Alive	30 sec.
Restart	120 sec.
<input type="button" value="Advanced"/>	<input type="button" value="Apply"/>

Keep Alive	Time period in seconds after which Keep Alive requests should be sent. These requests test whether the remote peer is still available. Default setting: 30 seconds.
Restart	Time period in seconds after which the connection to the remote peer should be restarted if there is no reply to the Keep Alive requests. Default setting: 120 seconds.

1.7.2.2 Port Forwarding


Rules for Port Forwarding: The router has only one IP address via which it can be accessed externally. Data packets can be redirected to internal IP address ports via additional transmitted port numbers.



Protocol	TCP, UDP, ICMP
In Port / To Port	(TCP and UDP only) You have the following options: To Port 1. direct port input - Example: In Port = 20, To Port = 30. 2. Port range - Example: In Port = 80-90 To Port = 100-110.
To IP	Input of a target IP address, 0.0.0.0/0 means all IP addresses.
Masq	For every individual rule, you can determine if IP masquerading should be applied. Yes: IP masquerading is activated, reply to VPN tunnel is possible. No: (Default) reply to VPN tunnel is not possible.
Comment	Input comment.

1.7.2.3 Certificates


Certificate for authentication of the router to the remote peer.



Certificates

Load Own PKCS#12	Upload	Upload the certificate (in PKCS#12 format, xxx.p12) to be used for the local router. Under VPN > OpenVPN > Client, you can assign one of these certificates to each VPN connection under Local Certificate.
	Password	Password with which the PKCS#12 file is protected during export.
Load CA certificate (.crt)	Upload	Upload the CA certificate.
Own Certificate	Name	Display the uploaded certificates and keys.
CA Certificate	Name	Display the uploaded CA certificates and keys.

1.7.2.4 Static Keys (Preshared Key)



Static Keys

Generate static Key	Click on "Save" to generate and save a static key file.
Load static Key	Upload : Upload the static key file. The same file must be uploaded to the remote peer's OpenVPN server.
Static Keys	List of uploaded static key files.

1.7.2.5 Status



OpenVPN Status

Active OpenVPN Connections	Status of the active VPN connection.
----------------------------	--------------------------------------

1.8 I/O

The router has an I/O input and output (Input/Output).

The router **input** behaves as follows:

Input Low: An input voltage of less than 5-6 volts is recognized as a Low signal.

Input High: An input voltage over 5-6 volts is recognized as a High signal. The maximum input voltage is 30V. Input current is limited to max. 4mA.

The physical behaviour of the router output is as follows:

Output Low: The output is highly resistant.


Output High: The operating voltage (10-30V) minus approx. 0.5V is switched to the outside. Its maximum load is 180 mA, following which the current limiter will be activated and the voltage will drop.

Example: If the router is operated using 24V, the "Output High" at the output will be approx. 23.5V.

In the case of "Output Low" there will be 0V at the output.

1.8.1 Inputs

The switch input can be used to send SMSs or email. Please check to see if the switch input is already being used to start a VPN connection. If so, it will not be possible to use it to send SMS or emails.




Inputs

High	When activated, an SMS or email will be sent when there is a "High" level at the switch input. Select the type of message and click "Apply". Then click "Edit". For SMS, select the corresponding phonebook entry and enter your message under "Message Text". For an email alert, fill out the email form.
Low	When activated, an SMS or email will be sent when there is a "Low" level at the switch input. Select the type of message and click "Apply". Then click "Edit". For SMS, select the corresponding phonebook entry and enter your message under "Message Text". For an email alert, fill out the email form.

Note: To send an email, the email account under the section 1.9.8 (see Page 40-41) SMTP Configuration must be set up.

1.8.2 Outputs

The router switch output can be controlled remotely or switched using a router connection status.



Outputs

Functions	Manual:	Switch the output by clicking ON or OFF in the web interface.
	Remote Controlled:	Switch the switch output remotely by SMS (see Page 13) or by Control command to the socket server (see page 14).
	Radio Network:	The switch output is active when the router is registered in a mobile service network.
	Paket Service:	The switch output is active when the router has established a packet data connection and received a valid IP address from the provider.
	VPN Service:	The switch output is active when the router has established a VPN connection.
	Incoming Call:	The switch output is active when the router is called from a call number entered in the phonebook (Caller ID).
	Connection Lost:	The switch output is active when the router connection check does not reach the configured address.
	Timer:	Reserved for timer functions.
Autoreset	"Autoreset" resets the switch output after the preset period of time.	

1.8.3 Phonebook

List of the call numbers for receivers of the SMS messages, as well as for authentication (Caller Id) for authorization to switch the outputs.

1.8.4 Socket Server

The router includes an integrated socket server and can be made to perform the following actions by receiving XML files:

1. Set and query I/O signals
2. Send messages such as email and SMS
3. Query the router status


To use these functions, the socket server must be set to "Enabled" in the socket configuration. The socket server port can be configured as desired, the default setting is Port 1432.

For examples of sending and receiving I/O status, email, SMS and router status using XML files via the router socket server see Section 2.2.1 (Page 47).

1.9 System

This section provides information on the hardware, software and status of the router.

1.9.1 Hardware




MC-MRL	
Hardware information	
Address	MC Technologies GmbH Kabelkamp 2 D-30179 Hannover
Internet	www.mc-technologies.net
Type	MC-MRL
Serial number	MC00002045
Hardware	Rev: B
Release version	1.02.4
Operating system	Linux 2.6.39.4
Web-based management	1.42.3
MAC address LAN1	D4-00-57-00-CC-00
MAC address LAN2	D4-00-57-00-CC-01
Radio engine	
Radio firmware	11.235.07.00.00
IMEI	

Hardware Information

Address	Address of the manufacturer.
Internet	Internet address of the manufacturer.
Type	Article description of the router.
Serial number	Serial number of the router.
Hardware	Hardware version of router.
Release version	Release version of router software.
Operating system	Version of operating system.
Web-based management	Version of web interface.
MAC address LAN1	MAC address of Ethernet Connection 1.
MAC address LAN2	MAC address of Ethernet Connection 2.
Radio engine	Type of cellular module used.
Radio firmware	Firmware version of the cellular module.
IMEI	The IMEI (International Mobile Station Equipment Identity) is a 15-digit serial number which can be used to accurately identify every cellular module.

1.9.2 Software

This menu item lists all the software modules installed, including their versions.



MC-MRL	
Software Information	
alertsd	0.90.1
busybox	1.18.5-1.7
conchkd	0.40.1
dnsmasq	2.57-1.2
dropbear	0.53.1-1.6
expat	2.1.0
ez-ipupdate	3.0.11b8-1.0
gsmCtrid	3.7.10
iproute2	2.6.38-1.3
ipsec	2.8.11-2.0
iptables	1.4.10-1.1
liboping	0.5.1-1.1
msmtp	1.4.27-1.0
openntpd	3.10p2-1.1
openssl	1.0.0l
openvpn	2.2.2-1.1
portmap	6.0-1.2
pppd	2.4.5-1.6
watchdog	0.17.2
xmlsrd	0.3.1


1.9.3 System Configuration

Web Configuration

The router web interface can normally be reached via the browser without additionally indicating a port by additionally indicating Port 80. The port can be changed here if needed.

Example using router address 192.168.0.1:

Web interface address: 192.168.0.1 or 192.168.0.1:80



System Configuration

Web Configuration

Server Port (default 80)

After changing the port to, for instance, 8080 address of the web interface: 192.168.0.1:8080

System Configuration

Web Configuration

Server Port (default 80)




Note: After clicking "Apply", perform a reboot (Page 44) or restart the router (interrupt the power supply).

Web server access

The router web interface can be accessed via http or https (secure) and/or http + https.

i Important note! This function is only supported by 4-port routers (MC xx-4) or 2 port routers (MC xx) with firmware beginning with 2.xx.x (See: "System / Hardware / Release" e.g. 2.04.2).




System Configuration	
Web configuration	
Server Port (default 80)	80
Web server access	http + https
HTTPS port (default 443)	443
Certificate validity	1825 days
HTTPS certificate	<input checked="" type="checkbox"/> Renew certificate

Web server access

Web server access	http: http access only. http + https: http and https access. https: https access only.
HTTPS port (default 443)	Alter the https default port here.
Certificate validity	Validity of the https certificate in days.
HTTPS certificate	Renew certificate: Local generation of an https certificate. Click again to renew the certificate.

Log Configuration

Log files can be saved on an external log server via UDP.



MC-MRH	
Log Configuration	
Remote UDP Logging	<input checked="" type="radio"/> Disable <input type="radio"/> Enable
Server IP Address	192.168.1.100
Server Port (default 514)	514
Non-volatile Log	USB Stick
<input type="button" value="Apply"/>	
Stop logging: done Start logging: [data storage device ready] done	

Log Configuration

Remote UDP Logging	Disabled: No logging on external server. Enabled: Logging on external server.
Server IP address	Server IP address.
Server Port (default 514)	Server port.
Non volatile Log	Disabled: Logging on the internal RAM. USB stick: Logging on the USB stick on the front plate. SD card: Logging on internal SD card. The SD card is not included in the scope of delivery.

Load Configuration

Load configuration	Disabled ▾
Configuration unlock	once ▾

Load configuration

Load Configuration	<p>Disabled: Uploading of the configuration from a USB stick or internal SD card is deactivated.</p> <p>USB stick: A configuration from a USB connected to the router has been uploaded.</p> <p>SD card: A configuration from the internal SD card has been uploaded.</p> <p>If the upload was successful, the setting is automatically set to "Disabled". The setting must be reconfigured to USB stick or SD card for a new upload.</p> <p>i Note: The internal SD card slot is accessible by removing the back cover.</p>
Configuration unlock	<p>once: The configuration is only uploaded once from the storage medium (USB stick or SD card).</p> <p>always: The configuration is always uploaded from the storage medium (USB stick or SD card) after the router is booted.</p> <p>by Input 1: The configuration is uploaded from the storage medium (USB stick or SD card) when there is a High signal from the input (I/O).</p>

Click "Apply" to save your configuration.

Reset button

To reconfigure the router using the default IP address or to set the configuration to the factory default settings you will need to use the configuration button on the rear side of the device (See Item 1.2.2). The following settings allow you to define which function should be permanently assigned to the configuration button.

Reset button	Web access reset ▾
<div>Apply</div>	




Reset button

Reset button	<p>Web access reset: Press the reset button to readdress the router web interface using the default IP address (192.168.0.1) for the Ethernet (LAN) connection. The configuration settings will not be lost when doing so.</p> <p>Factory reset: Press the reset button to readdress the router web interface using the default IP address (192.168.0.1) for the Ethernet (LAN) connection. All configuration settings will be deleted and reset to "Factory Default".</p>
--------------	--

Click "Apply" to save your configuration.

1.9.4 User




User Set-up

admin	Access to all areas - password modification (default: admin).
user	Only access - password modification (default: public).

1.9.5 Log File

All router activities are indicated in a log file. When the maximum storage capacity is reached, the oldest entries are overwritten.



Log File

Clear	All entries are deleted.
View	Log file display.
Save	Storage of the log file as a text file on a user PC.

1.9.6 ComSERVER (Only for MC Router with RS232 or RS485 interface on X1)

For remote access to terminal equipment with a serial interface, a virtual COM port connection can additionally be established over long distances as a standard router function.

MC Technologies MC-MRL, MC-MRH and MC-MRE routers are optionally equipped with an RS232 or RS485 interface at X1 for this purpose. For detailed information, please refer to the MC Technologies Application Note 41 Router (COM-Port connection via MC router - RS232/RS485).

Status	Disabled: The ComServer is deactivated. Enabled: The ComServer is activated.
Connection Type	Server RAW - Usage without RFC 2217 Client Server Protocol. Server RFC 2217 - Usage with RFC 2217 Client Server Protocol.
Server Port (default 3001)	Set the TCP port via which the ComServer is to be addressed.
Flow control	Set flow control: RFC 2217 - With an RS232 application RS485 RTS - With an RS485 application

Note: RFC 2217 is a Standard Client Server Protocol used as a standard protocol when using multiple device servers (ComServer.) The RFC 2217 protocol allows for the use of various "COM port redirector" softwares for virtual Com Port Interfaces on the PC.

1.9.7 SMTP configuration

SNMP Configuration

System information

Name of Device	For example: Device name.
Description	Short description.
Physical location	For example: name of the location.
Contact	For example: The admin's email address.

SNMPv1/v2 Community

Enable SNMPv1/v2 access	Yes: SNMP is supported. No: SNMP is not supported.
Read Only	Password for read only access.
Read and write	Password for read and write access.

Trap Configuration

Trap Manager IP address	Enter the recipient's IP address.
Port	Port (Default 162).
Target Community	Recipient's password.
Sending traps	Disabled: No traps are sent. Enabled: Traps are sent.

1.9.8 SMTP configuration - sending emails

To send emails as described under 1.8.1 Input (page 33), an email server must be configured with the support of the SMTP protocol. Please use your selected email account's access data.




SMTP Configuration

SMTP Server	Host name or mail server IP address.
Server Port (default 25)	Mail server port.
Transport Layer Security	None: Unencrypted connection to the mail server. STARTTLS: After STARTTLS encrypted connection to the mail server. SSL/TLS: Encrypted connection to the mail server via SSL/TLS.
Authentication	No authentication: No authentication required. Plain Password: Authentication using user name and password. Encrypted Password: Authentication using user name and password plus encrypted transmission.
Username	User name for logging onto the mail server.
Password	Password for logging onto the mail server.
From	Sender's email address.

1.9.9 Configuration Up-/Download

The configuration can be stored as a CFG file (default) or as an XML file on the user PC. Configurations stored on this PC can be uploaded to the router.




Configuration Up-/Download

Download	<p>Download: Store the current configuration in a file on a connected PC.</p> <p>USB stick: Store the current configuration in a file on a USB stick inserted into the router.</p> <p>SD card: Store the current configuration in a file on the internally inserted SD card (The SD card slot can be accessed by opening the rear housing panel).</p>
XML format	Check this box to save the configuration in XML format.
Upload	Upload a stored configuration.
Reset to Factory Defaults	The configuration is set to factory default settings. VPN certificates stored in the router are not affected.

i Note: Configuration using SSH and XML file.
The transfer of an XML file for router configuration can also be carried out using the SSH protocol via the local Ethernet interface or in remote operation. Please follow the description under 2.1 (Page 45).

1.9.10 RTC - Setting the time and date / Time Server



Real Time Clock (RTC)

New Time	Manually set the time when no time server (NTP server) is available.
NTP Synchronisation	<p>Disabled: No NTP synchronisation.</p> <p>Enabled: The router obtains date and time from a time server.</p>
NTP Server	<p>Local: Use a local NTP server.</p> <p>NTP - Network Time Protocol - The router can be used as an NTP server for a terminal device connected to "ETH1" or "ETH2". The terminal device must then use the router address as an NTP server. NTP synchronization must be set to "Enabled".</p>
Timezone	Timezone selection.
Daylight saving time	<p>Disabled: Without daylight saving time.</p> <p>Enabled: With daylight saving time.</p>
Time Server for Local Network	
Time Server	<p>Enabled: The router is operated as a time server in the local network.</p> <p>Disabled: The router is not a time server for the local network.</p>

1.9.11 Reboot - restarting the router

Reboot

Reboot NOW!	Router immediately shut down and then restarted.
Daily reboot	Set the day of the week for a reboot.
Time	Enter time of reboot in the format: Hour: Minute.
Event	Input1: A restart can be triggered via a HIGH signal to the switching input I/O IN. Please ensure that the switching input is ultimately set back to LOW to prevent another restart. None: No event for a reboot.

1.9.12 Firmware Update

Firmware Update Modem	Upload: Upload the latest firmware to the router.
Update Web Based Management	Upload: Upload the latest web interface to the router. Not required as standard because the web interface is included in the firmware and will also be revised when an update is issued.

2. Additional functions

2.1 Router configuration using SSH and XML file

The router can be configured using the SSH protocol via the local Ethernet interface or in remote operation.

SSH or Secure Shell refers to both a network protocol and a corresponding programme which allows an encrypted network connection to be generated using a remote device.

In **Linux**, use console input. In **Windows**, we recommend using the programs **plink.exe** and **pscp.exe**, which can be downloaded at putty.org.

The examples below are based on the router default settings:

Username: admin
Password: admin
Router IP-Address: 192.168.0.1

2.1.1 Download configuration via SSH

You can download the router configuration as an XML file or as a TGZ file.

For Linux:

```
ssh admin@192.168.0.1 'su -c "/usr/sbin/export_cfg" > config.xml'
oder
```

```
ssh admin@192.168.0.1 'su -c "/usr/sbin/export_cfg tgz" > config.tgz'
```

For Windows with PLINK.EXE

```
plink -2 -pw admin admin@192.168.0.1 "su -c \"/usr/sbin/export_cfg\" > config.xml"
oder
```

```
plink -2 -pw admin admin@192.168.0.1 "su -c \"/usr/sbin/export_cfg tgz\" > config.tgz"
```

2.1.2 Upload configuration via SSH

For Linux:

a. Without router reboot:

```
cat config.xml | ssh admin@192.168.0.1 'su -c "/usr/sbin/store_cfg"'
```

b. With subsequent router reboot:

```
cat config.xml | ssh admin@192.168.0.1 'su -c "/usr/sbin/store_cfg; /sbin/reboot"'
```

The password is requested interactively by SSH. An automatic batch operation is not possible. You can, however, use the "sshpass" programme to run a script file comprising the password. The script file (for example, `cfgupl.sh`) must contain the following:

```
#!/bin/bash cat config.xml | ssh admin@192.168.0.1 'su -c "/usr/sbin/store_cfg; /sbin/reboot"'
```

The Linux command is as follows:

```
sshpass -padmin ./cfgupl.sh
```

For Windows with PSCP.EXE and PLINK.EXE

a. Without router-reboot:

```
pscp -scp -pw admin config.xml admin@192.168.0.1:/tmp/cfg.xml
```

```
plink -2 -pw admin admin@192.168.0.1 "su -c \"/usr/sbin/store_cfg /tmp/cfg.xml\""
```

b. With subsequent router reboot:

```
pscp -scp -pw admin config.xml admin@192.168.0.1:/tmp/cfg.xml
```

```
plink -2 -pw admin admin@192.168.0.1 "su -c \"/usr/sbin/store_cfg /tmp/cfg.xml; /sbin/reboot\""
```

2.2 Sending and receiving IO status, email, SMS and router status using XML files via the router socket server

The router includes an integrated socket server and can do the following by receiving XML files:

1. Set and query I/O signals
2. Send messages such as email and SMS
3. Query router status

To use these functions, the socket server must be set to "Enabled" as described under 1.8.4 (Page 34). The socket server port can be freely configured, the default setting is port = 1432.

Socket Configuration	
Socket Server	<input type="radio"/> Disabled <input checked="" type="radio"/> Enabled
Server Port (default 1432)	1432
XML Newline Char	LF
XML Bool Values	Verbose
<input type="button" value="Apply"/>	

2.2.1 Sample for XML files

The following are a few examples of XML file content:

Example: Setting and querying the I/O signals

```
<?xml version="1.0"?>
<io>
<output no="1" value="1"/>
<input no="1"/>
</io>
```

Example: Sending an email

```
<?xml version="1.0"?>
<email to=name1@domain.de cc="name2@domain.de">
<subject>Test Mail</subject>
<body>Dies ist ein E-Mail-Text.
</body>
</email>
```

Example: Sending an SMS

```
<?xml version="1.0"?>
<cmgs destaddr="+49173 111223344">Dies ist der SMS-Text</cmgs>
```

Example: Querying router status

```
<?xml version="1.0"?>
<info>
<device />
<radio />
<ipsec />
<openvpn />
</info>
```

Example: Activate the packet data connection (ab xmlsrvd-0.4.3)

```
<?xml version="1.0"?>
<io>
<gprs value="1"/>
</io>
```

Example: De-activate the packet data connection (ab xmlsrvd-0.4.3)

```
<?xml version="1.0"?>
<io>
<gprs value="0"/>
</io>
```

Example: Activate the IPsec connection n (Replace n with the IPsec tunnel number)

```
<?xml version="1.0"?>
<io>
<ipsec no="n" value="1"/>
</io>
```

Example: De-activate the IPsec connection n (Replace n with the IPsec tunnel number)


```
<?xml version="1.0"?>
<io>
<ipsec no="n" value="0"/>
</io>
```

2.2.2 Functions test using Windows HyperTerminal

For a test in Windows, the programme "HyperTerminal" can be used. Hyperterminal can be used to send XML files to the router socket server. The corresponding (XML) files (see 2.2.1) must first be stored on your user PC.

Open Hyperterminal and configure the desired connection. (The example given uses the default settings):

Host address: 192.168.0.1 (Router / Socket Server IP-Address)
Connection number: 1432 (Socket Server Port)
Establish connection via: TCP/IP (Winsock)



Open the connection.

In the HyperTerminal menu "Transfer/send text file....", select the XML file to be transferred.



After transfer is complete, HyperTerminal displays the answer to your query.

2.3 Using the integrated GPS receiver in the MC-MRH router

This function is only available to you if you have an MC-MRH router with a GPS antenna connection.



The GPS coordinates (longitude and latitude) can be made available in different ways:

- In the web interface under "Status / Radio"
- By SMS as a reply to an SMS status request
- As a reply from the integrated socket server after receiving an XML file with status request

2.3.1 Activating the GPS function

Connect a passive or active GPS antenna to the "GPS" antenna terminal on the router. Please ensure that the GPS antenna has a "clear view" of the sky.

In the web interface, under "Wireless Network/Radio Setup" under "GPS Configuration" in the menu, select the type of antenna and click "Apply".



Note: If the setting "GPS configuration" is not visible, the GPS function is not activated for your router. If no antenna type is selected, no GPS data can be displayed.

2.3.2 Displaying the GPS coordinates in the web interface

Under "Status/Radio" in the menu, the data is displayed with the longitude and latitude values.

Radio Status	
Provider	Vodafone.de
Networkstatus	registered home
Signal Level	<div><div></div></div> -69 dBm
Packet Data	HSDPA/UPA online
Local Area Code	05E9
Cell ID	2620FCA
Latitude	52° 24.715457' N
Longitude	9° 43.953983' E

2.3.3 Receiving the GPS coordinates as an SMS

As described under 1.5.4 (SMS Configuration, Controlling the Cellular Router by SMS), a status notification can be requested by SMS.

#<password>:SEND:STATUS

When the GPS function is activated the GPS coordinates are transmitted in the SMS reply in addition to the status notification.

2.3.4 GPS coordinates as an XML file

As described under 2.2, the status of the router can be requested by sending an XML file to the socket server. When the GPS function is activated the GPS coordinates are transmitted in the status notification.